

Enabling Advanced Analytics in IP Cameras:

15/08/18

Provision-ISR is delighted to release the newly added video analytics.

This includes:

- 1) Face Detection
- 2) Crowd Gathering
- 3) People Counting
- 4) People Intrusion
- 5) Line crossing
- 6) Camera tampering
- 7) Object monitoring
- 8) Sterile area

Analytics can be enabled only on 8MP IP Cameras from “Eye-Sight” Series running v4.3 and up.
The model names are xxx-280IP5yyy. All models containing + support analytics.

Steps for enabling analytics:

- 1) Download the compressed file containing all the necessary files for this process by clicking [here](#).
- 2) Extract all the files from the downloaded file.
- 3) Update the IPC to the latest using the file “8MP Eye-sight 4.3.0.0(20394)20181204.tar”.
- 4) Run the program “Analytics Tool v3.2.0.5 for Eye-Sight 8MP.exe”
- 5) Browse and select the profile “8MP Eye-sight v4.3.0.fac”

Select a profile


- 6) Choose from the list all the cameras **from the same model**. **Please note:** setting the wrong camera model with the wrong profile might cause the camera to malfunction.
- 7) Choose from the “Product Type” Drop-down list the correct camera model.

Product Type	<div><div>I4-280IP5MVF</div><div>DAI-280IP5MVF</div></div>
--------------	--

For example: If you chose DAI-280IP5MVF for enabling the analytics, you should choose DAI-280IP5MVF from the “Product Type” List.

- 8) Click on “Set default configuration”. The camera will reboot automatically. **All settings and configuration will be restored to factory default.**

- 9) After the restart, Analytics will be enabled in the camera configuration menu.



Please feel free to contact our technical team with any question, concern or technical feedback.
Best Regards,
Provision-ISR Technical Department.